

PGA-03-BK	VOLCANO GUITAR AMPLIFIER 3 W. 9V BATTERY.	350
PL-10-BK	BOGEY GUITAR AMP, 10 WATT,"M" STYLE, BLACK	525
PL-10-OR	BOGEY GUITAR AMP, 10 WATT,"M" STYLE, ORANGE	525
PL-10-RD	BOGEY GUITAR AMP, 10 WATT,"M" STYLE, RED	525
PL-10-BR	BOGEY GUITAR AMP, 10 WATT,"M" STYLE, BROWN	525



PL-10-RD / -OR / -BK

PGA-03-BK

MG-10	GLX GUITAR AMPLIFIER 5W, 6" SPEAKER, HEADPHONES OUT	595
MG-40	GLX GUITAR AMPLIFIER 20W, 8" SPEAKER, CHANNEL A+B, CH+DL, MP3/AUX IN, PHONES OUT	1550
MGB-10	AS MG-10, BUT RECHARGEABLE. NO BATTERIES	675
MGB-20	AS MBG-10, BUT 10W, MIC / MP3 IN. NO BATTERIES	1175
MGB-PP	POWER PACK, FOR MBG-10. 10XAAA RECHARGEABLE	450



MG-10

MG-40

MGB-20

MX-15-R	GLX GUITAR AMPLIFIER 15W, 6" SPEAKER. SPRING REVERB.	1495
MX-35-R	GLX GUITAR AMPLIFIER 35W, 10" SPEAKER. SPRING REVERB.	1998
MX-60-R	GLX GUITAR AMPLIFIER 60W, 12" SPEAKER. SPRING REVERB.	3295

G-65-R	GLX GUITAR AMPLIFIER 65W, 10" SPEAKER, DSP, LINE IN, HEADPHONES OUT	2898
G-110-R	GLX GUITAR AMPLIFIER 110W, 12" SPEAKER, DSP, LINE IN, HEADPHONES OUT	3050

GS-35	GLX GUITAR AMPLIFIER 35W, 8" SPEAKER. AMP SIMULATION AND EFX. 6 USER SOUNDS.	2395
GS-65	GLX GUITAR AMPLIFIER 65W, 10" SPEAKER. AMP SIMULATION AND EFX. 6 USER SOUNDS.	3195
GS-125	GLX GUITAR AMPLIFIER 125W, 12" SPEAKER. AMP SIMULATION AND EFX. 6 USER SOUNDS.	3495
FS-2-GS	FOOTSWITCH, GLX. 2 BUTTONS. FOR GS-SERIES AMPLIFIERS.	350



MX-35-R

GS-SERIES MODELING AMP

AC-15	GLX ACOUSTIC GUITAR AMPLIFIER. 15W, 6" SPEAKER, CHORUS + DELAY, AUX/MP3 IN.	995
AC-30-R	GLX ACOUSTIC AMP, 30 WATT, BLACK, REVERB + 5-B EQ.	2095
AC-60-R	GLX ACOUSTIC AMP, 60 WATT, BLACK, REVERB	3398
GRA-30R	CLX ACOUSTIC AMP. 30 WATT. BLACK. REVERB.	1895



AC-15

AC-30-R

AC-60-R

GRA-30R

GT-20-B	GLX BASS AMPLIFIER 20W, 8" SPEAKER, HEADPHONES OUT.	1250
GT-35-B	GLX BASS AMPLIFIER 35W, 10" SPEAKER, LIMITER, LINE IN, HEADPHONES OUT, TILTED	2350
GT-80-B	GLX BASS AMPLIFIER 80W, 12" SPEAKER, LIM/CHORUS, LINE IN, HEADPHONES OUT, TILTED	2995
GT-150-B	GLX BASS AMPLIFIER 150W, 15" SPEAKER, LIM/CHORUS, LINE IN, HEADPHONES OUT, TILTED	4595
B-65	GLX BASS AMPLIFIER 65W, 10" SPEAKER CHO+DEL, LINE IN, HEADPHONES OUT	2295



GT-20-B



GT-80-B

CT-500H	GLX BASS AMPLIFIER HEAD. "COMPACT TOUR". 500W. 3,2KG.	5595
CT-5110	GLX BASS AMPLIFIER COMBO "COMPACT TOUR". 250W. 10" SPEAKER.	8695
CT-BRACKET	19" BRACKET FOR CT-500H. WITH BOLTS.	49
BC-210H	GLX BASS SPEAKER CABINET. 2X10" AND HORN. 300W.	3195
BC-410H	GLX BASS SPEAKER CABINET 4X10" AND HORN. 700W.	4795
BC-115H	GLX BASS SPEAKER CABINET. 1X15" AND HORN. 300W.	2650



CT-500H

BC-410H

BC-115H



CT-5110

COMBO BESTÅENDE AV 1X10" OG HORN PLUSS CT-500H.
FORSTERKEREN KAN ENKELT LØFTES UT AV COMBOEN
OG BRUKES SAMMEN MED STØRRE HØYTTALERKABINETTER.

	CE-100	CHORUS ENSEMBLE	720		GPS-05-EU
	CH-100	CHORUS	655		GPS-800-EU
	CS-100	COMPRESSION SUSTAINER	495		GPS-CAB01
	DD-050	DIGITAL DELAY	595		
	DD-100	DIGITAL DELAY	1495		
	DS-100	DISTORTION	530		
	EQ-100	GUITAR EQUALIZER	619		
	FL-100	FLANGER	529		
	HM-100	HEAVY METAL	639		
	NG-100	NOISE GATE	530		
	OC-100	OCTAVER	619		
	OD-100	OVERDRIVE	549		
	PH-100	DIGITAL PHASER	1495		
	RV-100	DIGITAL REVERB	1495		
	SD-100	SOFT DISTORTION	449		
	AC-100	ACOUSTIC SIMULATOR	610		
	BCH-1	BASS CHORUS	629		
	BEQ-1	BASS EQUALIZER	649		
	BLM-1	BASS LIMITER	495		
	BOD-1	BASS OVERDRIVE	595		
GPB-05-EU	PEDAL BOARD W/CABLES AND POWER SUPPLY FOR 5 STOMP BOXES		1695		
GPS-800-EU	POWER SUPPLY FOR STOMP BOX/ PEDAL BOARD, 9V 800MA NEG. TIP.		189		
GPS-CAB01	POWER DISTRIBUTION CABLE , 1 MALE / 7 FEMALE CONNECTORS		110		
GPS-CAB02	POWER DISTRIBUTION CABLE , 8 FEMALE CONNECTORS		110		
VP-100	VOLUME PEDAL, "BOSTON". STEREO, MIN. VOLUME, PAR. TUNER OUT. METAL HOUSING.		950		
CB-200	WAH WAH, "BOSTON". METAL HOUSING. BATTERY INCL.		999		
BFS-15	ON/OFF SWITCH, "BOSTON", PLASTIC MODEL. 3M FIXED CABLE.		150		